


mayer

Electronic Kitchen Scale MMEKS5



Warranty & Customer Service

SCAN FOR



e-Warranty

e-Warranty Registration at <https://khindonline.com/login>

MAYER MALAYSIA SDN BHD

(Formerly known as Khind Alliances Sdn. Bhd.)

Customer Service Hotline: 1800-88-0032

Service Centre Operating Hours:

8.30am – 6.00pm (Monday - Friday)

Closed on Saturday, Sunday and Public Holidays

No. 2, Jalan Astaka U8/82, Bukit Jelutong, 40150 Shah Alam, Selangor D.E., Malaysia.

Waranti & Perkhidmatan Pelanggan

IMBAS UNTUK



E-Waranti

Pendaftaran e-Waranti di <https://khindonline.com/login>

MAYER MALAYSIA SDN BHD

(Sebelum ini dikenali sebagai Khind Alliances Sdn. Bhd)

Hotline Perkhidmatan Pelanggan: 1800-88-0032

Waktu Operasi Pusat Perkhidmatan:

8.30am – 6.00pm (Isnin-Jumaat)

Ditutup pada hari Sabtu, Ahad dan Cuti Umum

No. 2, Jalan Astaka U8/82, Bukit Jelutong, 40150 Shah Alam, Selangor D.E., Malaysia.

Please read this instruction manual thoroughly before operating and keep it for future reference


IMPORTANT SAFETY INSTRUCTIONS

- Please put the scale on hard and flat surface and make sure it is steady before use.
- The maximum capacity of the scale is 5kg, which is the weight before tare.
- Please use soft tissue with alcohol or glass cleaner to clean the surface if it is dirty. Do not use soap or other chemicals. Keep it away from water, corrosive liquid, heat and extreme coldness.
- The scale is a high precision measuring device and has a fragile glass surface. Do not knock it heavily or try to disassemble it and please handle it carefully to avoid dropping or breaking when using or moving it from one place to another. Do not stack any heavy items on top of the scale.
- The scale is for family use only and not suitable for professional use.
- Please check the battery if the scale malfunctions. Change to a new one if necessary. For other problems, please contact the Service Centre.
- Please change a new battery when “LO” appears on the screen which indicates that the battery is out of power.
- “O-Ld” shows on the screen which indicates overload.

PRODUCT TECHNICAL PARAMETERS

MODEL	VOLTAGE	MAXIMUM CAPACITY
MMEKS5	3V	5 kg

INTRODUCTION OF PARTS



1. “ON/TARE” Button: Power on, power off and weight zero function
2. “UNIT” Button: Unit exchange (g/fl.oz/oz/ml/lb)

Measurement Abbreviations	
g	Grams
fl.oz	Fluid Ounce
oz	Ounce
ml	Milliliter
lb	Pounds

CONTROLS AND OPERATIONS

1. Place the scale steadily on hard and flat surface. It is recommended to put on a clean, solid and smooth surface table.
2. Press the “ON/TARE” button to switch on the scale. When the screen display shows "0g", this means that the scale is on standby mode and it is ready to use.
3. Press the “UNIT” button and you can choose from the different units (g / fl.oz / oz / ml / lb)
4. Put the items you want to use to weigh the ingredients (e.g. measuring cup, bowl, etc.) on the scale and the weight will be shown on the screen display.
5. Press the “ON/TARE” button again to clear the weight of the item on the scale and the screen display will reset and show "0g". Then place the food ingredient on the item which is on the scale, and the weight of the ingredient added will be shown on the display screen.
6. Continue to use the “ON/TARE” button to get the respective weight of more ingredients in the same measuring cup / bowl used, through repeating tare conveniently.
7. When all the items and ingredients are removed from the scale, the screen display will show the total weight of everything that was placed on the scale.
8. Press the “ON/TARE” button to switch off the scale when the screen shows “0g” and if no more weighing is needed. Alternatively, the scale will power off automatically if it is not in use after a period of time.